


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-BBT-208V-277V-46.88A



TRANSFORMER 2 OF 2

1. Connect X2 and X3 together
2. Connect H2 and H3 together
3. Connect High Voltage L1 to X4
4. Connect Low Voltage L1 to H4 and X1
5. Connect High & Low Voltage L2 to H1

TRANSFORMER 1 OF 2

1. Connect X2 and X3 together
2. Connect High Voltage L1 to X4
3. Connect Low Voltage L1 to X1, H4, H2
4. Connect High & Low Voltage L2 to H1 and H3