


Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

TX-480D-6KVA-240D



PRIMARY VOLTS	
CONNECT LINES TO H1, H2, H3	
TAP	VOLTAGE
1	480
2	456
3	432

SECONDARY VOLTS	
CONNECT LINES	VOLTAGE
X1, X2, X3	240