NEMA 3R Deep Cycle Battery Box
Instruction Manual

Do not attempt installation until you are familiar with all warnings, precautions, and procedures outlined within this instruction sheet.

WARNING:

READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.
CRITICAL SAFETY INSTRUCTIONS:

- RISK OF FIRE OR ELECTRIC SHOCK. INSTALLATION REQUIRES KNOWLEDGE OF BATTERY STORAGE/ELECTRICAL SYSTEMS. IF NOT QUALIFIED, CONTACT A QUALIFIED ELECTRICIAN.
- TO PREVENT WIRING DAMAGE OR ABRASION, DO NOT EXPOSE WIRING TO EDGES OF SHEET METAL OR SHARP OBJECTS. SUITABLE FOR DAMP LOCATIONS.

INSTALLATION

This outdoor rated battery box is capable of securing one deep cycle battery with dimensions up to 13-1/18" x 7-1/16" x 11-3/8"

Box Dimensions: 14" x 8" x 12"

Mount following the steps below:

1. Remove top bolts to remove lid
2. Remove wing nuts holding the battery holder
3. Install battery
4. Replace battery holder
5. Replace top lid and tighten all bolts

This light is “instant-on” and will illuminate once power is supplied to the unit. DO NOT look directly at LED’s when powering.

USE AND CARE

Always check damaged or worn out parts before using the work light. Broken parts may affect operation. When not in use, store work light in a secure place. Inspect it for good working condition prior to storage and before re-use.

Should further information not covered by these instructions be required, please contact Larson Electronics at 1-800-369-6671 or sales@larsonelectronics.com for further assistance.

Please visit LarsonElectronics.com for **Warranty** and **Return** information.