Larson Electronics LLC www.LarsonElectronics.com sales@larsonelectronics.com
9419 E US HWY 175, Kemp, TX 75143 - P: (800) 369-6671 - F: (903) 498-3364

GAU-SLED-10 Series

Before installing, read the following instructions for safe and proper installation.

WARNING: The supply circuit should be disconnected when installing, relamping or performing any maintenance on the fixture.

PENDANT MOUNTING

1. Thread the fixture onto the conduit, sealing around the conduit using approved NEC procedures. Flats are provided at the top of the fixture to tighten with a wrench.
2. After securing to the conduit, tighten the set screw.

WALL MOUNTING

1. Remove the wiring box from the arm and attach box to the mounting surface.
2. Pull leads to the box and through the arm to the wiring chamber.
3. Attach the arm to the wall box.
4. The mounting screws should be tightened in alternate sequence.

CEILING MOUNTING

1. Attach fixture to mounting surface using the two mounting tabs provided.

WIRING THE FIXTURE

1. Remove the wiring access plug. Connect neutral to white fixture wire and line to black fixture wire.
2. Make all wiring connections in accordance with accepted NEC wiring procedures.
3. Be sure any unused wiring entrances are closed with closure plugs.

LAMP INSTALLATION

1. Unscrew globe cover
2. Unthread the glass globe from the fixture.
3. Install lamp.
4. Reinstall glass globe and globe cover.

WARNING: The globe is tempered glass. Do not scratch or chip. Turn the power off before starting installation, repair or relamping.