48 Watt Portable LED Telescoping Light Pole
Instruction Manual

Do not attempt operation until you are familiar with all warnings, precautions, and procedures outlined within this instruction sheet. Read carefully before operating. Retain these instructions for future reference.

WARNING:

- KEEP PLUGS AND RECEPTACLES DRY.
- LAMP RATED IP68 WATERPROOF.
- DO NOT TOUCH HOT LENS OR ENCLOSURE.
- DO NOT REMAIN IN LIGHT IF SKIN FEELS WARM.
- DO NOT LOOK DIRECTLY AT LIGHTED LAMP.
- KEEP LAMP AWAY FROM MATERIALS THAT MAY BURN.

USING THE TRIPOD

1. Utilize the predrilled holes and mount the flat bracket in a location that can support the load.
2. Place telescoping pole in base mount and tighten base mount hand screw until snug.
3. Place light head over the top pole and tighten hand screw.
4. Loosen the black adjustment knob for each adjustment sleeve to extend the tripod. Start with the top section when lifting.
5. Tighten adjustment knob once desired height is achieved.



VEHICLE WIRING

- Connect cord to light and coil cord via deutsch connectors and attach power cord to **Voltage:** 9-42V DC cigarette plug receptacle.

TRANSFORMER WIRING

- Connect straight cord to light and transformer via deutsch connectors and attach power cord from transformer to **Voltage: 120-277V AC receptacle.**

LED OPERATION

This light is "instant-on" and will illuminate once power is supplied. Do not look directly at LED's when turning on.

USE AND CARE

Always check damaged or worn out parts before using the work light. Broken parts will affect operation. When not in use, store work light in a secure place out of the reach of children. Inspect it for good working condition prior to storage and before re-use.

MAINTENANCE

Maintain your work light. It is recommended that the general condition of any work light be examined before it is used. Keep your work light in good repair by adopting a program of conscientious repair and maintenance. Have necessary repairs made by qualified service personnel.

Should further information not covered by these instructions be required, please contact Larson Electronics at 1-800-369-6671 or sales@larsonelectronics.com for further assistance.

Please visit LarsonElectronics.com for **Warranty** and **Return** information.