15W Explosion Proof LED Handlamp - 2,400 Lumens - 120-277V AC - Frosted Lens - 360° - NO Cord Instruction Manual

Do not attempt operation until you are familiar with all warnings, precautions, and procedures outlined within this instruction sheet. Read carefully before operating. Retain these instructions for future reference.

WARNING:

USER SHOULD BE TRAINED IN THE PROPER USE AND MAINTENANCE OF THIS DEVICE. WHEN HANDLAMP IS CONNECTED TO POWER SOURCES OUTSIDE OF HAZARDOUS AREA, STANDARD DUTY PLUGS AND RECEPTACLES MAY BE USED.

STANDARD PLUG AND TRANSFORMER MUST ONLY BE CONNECTED TO A RECEPTACLE LOCATED OUTSIDE THE HAZARDOUS AREA!
IMPROPER USE OF THIS HANDLAMP, ASSOCIATED PLUG, RECEPTACLE, AND CORD CAN LEAD TO SERIOUS INJURIES OR DEATH TO PERSONNEL.

PERIODIC INSPECTION OF THE HANDLAMP AND CORD IS NECESSARY.

THE CORD MUST BE ROUTINELY CHECKED FOR CUTS, BREAKS, OR ANY SEVERE ABRASIONS, AND IF ANY ARE FOUND, THE CORD MUST BE REPLACED BEFORE RESUMING USE OF THE HANDLAMP.

THE GLOBE IS MADE OF TEMPERED GLASS. IF THIS GLASS BECOMES SCRATCHED OR CHIPPED DISCONTINUE USE AND REPLACE IMMEDIATELY.

USING THE HAND LAMP

This hand lamp comes preconfigured with user selected cord cap. Pictures shown may vary. Follow the steps below to operate the unit.

1. Position light head in desired location using the swivel hook.
2. Attach Cord. The EHL-LED-ITG-DW does not come equipped with a cord or cord cap. Operators provide their own cord and cord cap. The runner cord grip on this handlamp accepts 16/3 SOOW, 14/3 SOOW, 12/3 SOOW, and 10/3 SOOW cord.
3. Run cable and attach power cord to compatible outlet outputting **voltage listed on product label. Power must be connected OUTSIDE the Hazardous Area.**

WARNING: *Check product label for correct voltage! Damage from improper voltage may not be covered by warranty.*



OPERATION

The LED lamp in the hand lamp is “instant-on” and will illuminate once power is supplied.

USE AND CARE

Unauthorized modification may impair the function and/or safety of the work light and could affect the life of the equipment. Always check damaged or worn out parts before using the work light. When work light is not in use, store it in a secure place out of the reach of children. Inspect for good working condition prior to storage and before re-use.

REPLACEMENT PARTS

The EHL-LED-ITG-DW is designed to provide years of reliable lighting performance. Should the need for replacement parts arise, please contact Larson Electronics at the contact information below.

Should further information not covered by these instructions be required, please contact Larson Electronics at 1-800-369-6671 or sales@larsonelectronics.com for further assistance.

Please visit LarsonElectronics.com for **Warranty** and **Return** information.