Rechargeable Battery-powered Electrostatic Sprayer 9.84' Spray Distance - 0.47G Tank Capacity - No-Contact Disinfection Instruction Manual

Thank you for your purchase of the Larson Electronics IND-MD-DF-ESR-R1.

WARNING:

READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.
CRITICAL SAFETY INSTRUCTIONS:

- INSTALLATION SHOULD ONLY BE CONDUCTED BY A QUALIFIED ELECTRICIAN IN ACCORDANCE WITH NEC AND ANY RELEVANT LOCAL BUILDING CODES.
- RISK OF FIRE OR ELECTRIC SHOCK. FIXTURE INSTALLATION REQUIRES KNOWLEDGE OF LUMINAIRES ELECTRICAL SYSTEMS. IF NOT QUALIFIED, CONTACT A QUALIFIED ELECTRICIAN.
- BE CERTAIN ELECTRICAL POWER IS OFF BEFORE AND DURING INSTALLATION AND MAINTENANCE.
- MAKE SURE THE SUPPLY VOLTAGE IS THE SAME AS THE RATED LUMINAIRE FIXTURES VOLTAGE.
- TO PREVENT WIRING DAMAGE OR ABRASION, DO NOT EXPOSE WIRING TO EDGES OF SHEET METAL OR SHARP OBJECTS. SUITABLE FOR DAMP LOCATIONS.

The Larson Electronics IND-MD-DF-ESR-R1 Rechargeable Battery-powered Electrostatic Sprayer is a no-contact disinfection solution for hard-to-reach surfaces in work sites, outdoor areas, gyms, offices, daycare centers, warehouses, airports, healthcare facilities, and more. This wireless device sprays a mist consisting of a sanitizing agent, which applies an even coating on surfaces and equipment. Equipped with a 0.47-gallon tank capacity, the sprayer comes with a power charger, 2200 aH lithium-ion battery, nozzle, and screw-on tank.

BATTERY

The IND-MD-DF-ESR-R1 is powered by an 2200aH lithium-ion battery, which offers a runtime of 30 minutes per full charge. A wall charger that operates on 110 V, 50/60 Hz is included with the unit. The battery is field replaceable to extend runtime. From a completely depleted state, the battery will take 3 hours to fully recharge. The battery is removable for charging convenience and features a charge level indicator light.

MOUNTING

Equipped with a handle, this wireless disinfection device is designed for portable use to allow maximum reach of areas and surfaces.

MAINTENANCE

There are no serviceable parts inside the fixture. However, it is good practice to routinely clean and check the fixture for proper function.

- Disconnect power running to the unit and be sure the fixture is cool to the touch.
- Use a non-abrasive cleaning solution to clean the unit.

USE AND CARE

Unauthorized modification may impair the function and/or safety of this device and could affect the life of the equipment. Always check for damaged or worn out parts before using the device. Store it in a secure place out of the reach of children when not in use. Inspect for good working condition prior to storage and before re-use.

REPLACEMENT PARTS

The IND-MD-DF-ESR-R1 is designed to provide years of reliable performance. Should the need for replacement parts arise, please contact Larson Electronics.

THESE INSTRUCTIONS MAY NOT COVER ALL DETAILS OR VARIATIONS OF THIS PRODUCT FOR YOUR EQUIPMENT OR INSTALLATION REQUIREMENTS. SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT SALES@LARSONELECTRONICS.COM OR BY PHONE AT 1-800-369-6671 FOR FURTHER ASSISTANCE.

PLEASE VISIT LARSONELECTRONICS.COM FOR **WARRANTY** AND **RETURN** INFORMATION.