Larson Electronics LLC www.LarsonElectronics.com sales@larsonelectronics.com
9419 E US HWY 175, Kemp, TX 75143 - P: (800) 369-6671 - F: (903) 498-3364

LEDWP-720

Important: Please read carefully before installation and retain for future reference.

- To prevent possible shock hazard, the fixture should be installed by a qualified licensed electrician.
- All electrical connections must be in accordance with local codes, ordinances and National Electrical Code.
- The use of safety protection such as safety eye glasses and protective gloves are recommended.
- Proper grounding of the fixture is essential for protection from shock, correct operation and the elimination of electrical interference.

Danger: Risk of electrical shock. Turn off main power source before servicing.

Always transport and store the equipment in its original packaging and keep in a dry location. When unpacking check for any cracks or damage to casting and glass lens, if in doubt do not install!

INSTALLATION:

Important: Make sure application surface can handle weight of light fixture.

1. Securely mount lower mounting bracket to application surface.
2. If installing other than 90°, loosen, but DO NOT remove, pivoting bolts. (top bolt)
3. Remove angle locking bolts. (bottom bolt)
4. Pivot to desired angle, replace and tighten angle locking bolts.

WIRING:

1. Once the module has been mounted in place, remove access cover by unthreading mounting screws.
2. Insert source wire cable through cable gland provided on module.
3. Slip cable through cable holder provided to secure cable during installation.
4. Connect source wires to terminal block.
    - Connect the source GROUND wire to TERMINAL
    - Connect the source NEUTRAL wire to TERMINAL – “N”
    - Connect the source LIVE wire to TERMINAL – “L”

    Ensure all wire terminal screws are tightened.
5. Once source wires are connected, restore power and check for illumination.
   CAUTION: Do not look directly into fixture once powered and lit. Use protective shaded eye wear when viewing.

6. Replace access cover by securing the mounting screws on the access cover. Recommended torque – 10 in lb

WARNING: To retain seal integrity (and preserve warranty) do not loosen or remove any of the bolts around the perimeter of the module. There are no serviceable components in the module. Removal or loosening of any of these bolts will void all warranties.

SAFETY CABLE

Safety cable tabs have been mounted directly to the module allowing the assembly of a safety cable or chain.