Larson Electronics LLC www.LarsonElectronics.com sales@larsonelectronics.com
9419 E US HWY 175, Kemp, TX 75143 - P: (800) 369-6671 - F: (903) 498-3364

EXP-LED-3C

OPERATION

- Push tail cap switch button to turn flashlight on and off.
- Slightly depress the button for momentary signaling.

LED REPLACEMENT

LED never needs replacement.

BATTERY REPLACEMENT

- Use only alkaline batteries. Replace all the batteries at the same time.
  WARNING: Improper battery installation can cause the batteries to explode or leak and cause personal injury. Do not mix battery types or new with used batteries. Observe polarity during installation.
- Install batteries with positive tip facing bulb end. If your light fails to operate, always check batteries first.

MAINTENANCE

- The light can be cleaned with soap and water. Do not use solvents.
- Keep head “0” ring lubricated with Silicone grease.
- Keep the inside dry and clean.
- If the light should fail to operate, first make sure the batteries are good and installed correctly.

This product has been tested and approved for use in Potentially Explosive Atmospheres (see product for specific ratings). This approval is only valid when the apparatus is used and maintained in accordance with the accompanying instructions and only within the marked product class or category shown. You, the user, are responsible for the correct application of this product.

CAUTION: For use in potentially hazardous areas:

- Do not open in a potentially explosive area/zone.
- Always observe proper battery replacement procedures (see “Battery Replacement”).
- Clean only with a damp cloth in a nonhazardous area.
- Use only those lamps and batteries “approved” for use with the product. Substitution may impair safety.