
Wiring Diagram

WARNING: *DO NOT SERVICE WHILE ENERGIZED!*

ETX-3P-690D-10KVA-480Y.277



Primary Volts	Connect Lines To	Inter-connect
655	H1, H2, H3	1
690	H1, H2, H3	2
725	H1, H2, H3	3

Secondary Volts	Connect Lines To	Inter-connect
480	X1, X2, X3	-
277 1 phase	X1 to X0 X2 to X0 X3 to X0	-

LARSON ELECTRONICS LLC • 9419 E US HWY 175 • KEMP, TX 75143
p: 1-800-369-6671 • intl: 903-498-3363 • f: 903-498-3364 • sales@larsonelectronics.com