
# Wiring Diagram

***WARNING:*** *DO NOT SERVICE WHILE ENERGIZED!*

## EPF-RME-16-0.25HP-PR-M1


Connect the motors of all fans according to the diagrams inside the terminal box cover or on the nameplate. **BE SURE TO CONNECT FOR THE VOLTAGE, FREQUENCY AND PHASE TO BE USED.**




INTERCHANGE 5 AND 8 LEADS TO REVERSE ROTATION

Dual-voltage single phase motors are factory-connected for 230 volt lines. Dual-voltage three-phase motors are factory-connected for 460 volt lines. Provide Nationally Recognized Testing Laboratory recognized electrical overload protection not to exceed 125% of the marked input rating of the fan motor.


LARSON ELECTRONICS LLC • 9419 E US HWY 175 • KEMP, TX 75143
p: 1-800-369-6671 • intl: 903-498-3363 • f: 903-498-3364 • sales@larsonelectronics.com




| | | | |
|---|---|---|---|
| LARSON ELECTRONICS<br>9419 E US HWY 175,<br>KEMP, TX 75143 | TITLE: EPF-RME-16-0.25HP-PR-M1 | | |
| | DRAWN BY: R.BLACK | DATE: 01/28/2022 | REV: A |
| | CHECKED BY: K.NGUYEN | SHEET # | DRAWING #: 101 |