
Wiring Diagram

WARNING: *DO NOT SERVICE WHILE ENERGIZED!*

EPF-RME-18-0.5HP-PR-M1


Connect the motors of all fans according to the diagrams inside the terminal box cover or on the nameplate. **BE SURE TO CONNECT FOR THE VOLTAGE, FREQUENCY AND PHASE TO BE USED.**



INTERCHANGE 5 AND 8 LEADS TO REVERSE ROTATION

Dual-voltage single phase motors are factory-connected for 230 volt lines. Dual-voltage three-phase motors are factory-connected for 460 volt lines. Provide Nationally Recognized Testing Laboratory recognized electrical overload protection not to exceed 125% of the marked input rating of the fan motor.

LARSON ELECTRONICS LLC • 9419 E US HWY 175 • KEMP, TX 75143
p: 1-800-369-6671 • intl: 903-498-3363 • f: 903-498-3364 • sales@larsonelectronics.com



LARSON ELECTRONICS 9419 E US HWY 175, KEMP, TX 75143	TITLE: EPF-RME-18-0.5HP-PR-M1		
	DRAWN BY: R.BLACK	DATE: 01/28/2022	REV: A
	CHECKED BY: K.NGUYEN	SHEET #	DRAWING #: 101