
Wiring Diagram

WARNING: *DO NOT SERVICE WHILE ENERGIZED!*

MT-CTX-600V-150VA-120V



Connections	
Primary Volts	Primary Lines Connect To
600	H1 - H2
Secondary Volts	Secondary Lines Connect To
120	X2 - X1

LARSON ELECTRONICS LLC • 9419 E US HWY 175 • KEMP, TX 75143
p: 1-800-369-6671 • intl: 903-498-3363 • f: 903-498-3364 • sales@larsonelectronics.com