

HL-85-LED-CPR

36 Watt Pistol Grip LED Spotlight Instruction Manual

Thank you for your purchase of the 36 Watt LED Pistol Grip Spotlight, the following instructions are intended for this part number only. This light features a coil cord with cigarette plug for easy instant use.

To begin operating the spotlight, plug in the cigarette adapter to any 12-24V DC power outlet. Each unit is configured for either 12 volts or 24 volts DC. The 12 volt models can be plugged into 12 volt DC power supplies, which most consumer vehicles operate on. The 24 volt models can be plugged into a 24 volt DC power supply, generally for military and heavy equipment.

Once plugged in, simply press the button to activate and deactivate the light.

Power transformers (DCP-11-DP) can be purchased through our website to run this halogen spotlight from household wall outlets.

The HL-85-LED-CPR Spotlight is IP67 Waterproof, dustproof, shock proof, impact and vibration resistant.



Safety Warnings

For personal safety, always follow the safety instructions in this manual to ensure safe and long-term use. Failing to do so can result in damage to the product or serious bodily injury

Warnings

To prevent serious damage to eyesight, never look into spotlight when light is on. **DO NOT** shine light into the face of someone else.

DO NOT touch lens of spotlight when light is on or if it was recently on. The lens will be hot and could cause serious burns.

DO NOT allow children to handle or operate this light.

DO NOT use this product for other than its intended use.

DO NOT operate in close proximity of Combustible or flammable materials.

DO NOT attempt to operate this light if cord, plug, battery, bulb or any part of the light is damaged or corroded.

DO NOT leave the light facing down while light is on, this could start a fire.

For info on warranty and returns please visit our website: www.Larsonelectronics.com