



HL-85-HID-80W-CPR

USE & SAFETY TIPS

1. DO NOT leave light connected to a power source when not in use.
2. DO NOT place light face down on any surface. If the light is switched on, the intense heat generated may ignite the surface and cause a meltdown of the lamp body.
3. Ensure all electrical connectors are secure. Loose connections will generate excessive heat, damage wiring, and cause electrical failure.
4. DO NOT attempt to clean the inside of the light or touch the inside lens and reflector.
5. Lights are not designed to be used for long periods of time in a stationary position with minimal airflow; failure to comply will void warranty.
6. Focusing Mechanism: The focus mechanism allows precise adjustment of the beam to various concentration patterns as desired. Simply rotate the reflector and select the desired SPOT.
7. Shortening the cable length may result in a shorter lamp life.
8. During use, ensure that the reflector is recessed on the lamp head. Operating the light while the reflector is not on the lamp head properly may result in melting of the housing and is not covered under warranty.
9. Larson Electronics is not liable for damage, malfunctions, failure resulting from accidents, misapplication, misuse, unauthorized repairs, neglect, modifications, unauthorized or nonstandard replacement parts, accessories, globes, batteries, voltage, or the operation of the product beyond its technical and environmental specifications. The purchaser acknowledges that local laws may prohibit the use of this product on motor vehicles, on public roads, and agrees that it's their responsibility to ascertain the effect of local laws.