

MUL

Handheld Utility Light with Magnetic Base Instruction Manual

Thank you for your purchase of the MUL Series Handheld Utility Light with Magnetic Base. These instructions will cover how to operate the light as well as bulb replacement.

The light features a magnetic base that allows it to attach to any metal surface – the mount has gripping power up to 100lbs. When removing, do not drag the magnetic base to disconnect, as it may scratch the surface/paint.

OPERATION

- Place on metal surface.
- Adjust tightness of tilt movement using the tightening bolts on sides of base hinge.
- Connect SAE/Deutsch connector from power cord to light.
- Plug power plug into power source. For models with power switch, flip the switch to turn light on/off.

NOTE: Check for proper voltage before use! Power options range from 12v DC to 24v DC. Each model requires a specific voltage and may not be variable.

BULB REPLACEMENT (Non-LED Round Model)

To replace the bulb remove the screw on the bottom of the face ring. If you have the model with the rubber lens ring, it will not have a screw to remove and must be pried from the fixture. Take the face ring off of the lamp and pull the bulb out of the socket freeing it from the spring fasteners. Place the new bulb in its socket and replace face ring.



For info on **Warranty** and **Returns** please visit our website: www.LarsonElectronics.com