

## Three Year Limited Warranty

Golight, Inc. warrants the Golight® against any deemed defects that are due to workmanship for parts or faulty materials, **except lamps**, for three years from the date of the original purchase. This warranty to the Golight® does not cover damage resulting from unreasonable use or misuse, unreasonable maintenance or loss, or labor costs.

Mounting the light upside down will void the warranty.

Warranty cards must be filled out and sent in within 30 days of purchase to Golight, Inc. • RT 3 Box 37B • Culbertson, NE 69024, for warranty protection. Register online at [www.golight.com](http://www.golight.com).

If the Golight® does fail to operate under warranted specifications, send the **light and remote controls** postage paid, plus \$9.95 for shipping and handling to: Golight, Inc. • Service Department • RT 3 Box 37B • Culbertson, NE 69024. No C.O.D.'s accepted. Only the above manufacturer is authorized to perform warranty repair or replace product.

Any consequential damages to person or property are excluded from this warranty. Some states do not allow the exclusion and limitation of incidental or consequential damages, therefore the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights.

[www.magnalight.com](http://www.magnalight.com)  
1-800-369-6671  
903-498-3363  
[sales@magnalight.com](mailto:sales@magnalight.com)

# GOLIGHT®

## MODELS 5149, 5167

### Congratulations

You are now the owner of one of the finest remote control searchlights available today. Thank you for letting Golight® assist you in your lighting application needs. We're proud of our products and the technology that we've developed to ensure our customers the most durable, versatile and powerful searchlights in the lighting industry.

Please read these instructions before using your new Golight®.



U.S. Patent 5,490,046

Instruction Guide

The Golight® is a Portable Searchlight designed to be permanently or temporarily attached to a vehicle for your specific use. The Searchlight with Directional Flexibility is controlled by a wired remote, which gives the operator a full 370° horizontal rotation and a 135° vertical tilt with fingertip control. The Golight® provides superior light penetration with Cr5 PentaBeam™ technology.

The Golight® Includes:

- Golight® Searchlight  
(Free-standing light with suction mounting.)
- Wired Remote Control (Must be kept clean and dry.)
- Permanent Mounting Shoe  
(Press spring lock to release and remove light.)
- Permanent Mounting Gasket
- Rockguard
- An Optional Magnetic Shoe (See Accessory Sheet)

#### MOUNTING INSTRUCTIONS — TEMPORARY:

1. Always clean mounting surface with a clean cloth.
2. Remove light from permanent mount shoe by depressing spring loaded lock and sliding light out.
3. Place suction base on clean, dry surface and move side lever into the locked position.

**WARNING:** Suction mount is for temporary use only. Check the suction cup frequently to ensure that suction strength is maintained. Temperature variations, rough terrain, grease and dirt affect the length of time that the suction cup will remain in place.

#### MOUNTING INSTRUCTIONS — PERMANENT:

1. On clean, dry surface, place gasket and shoe in desired location. Using 3/16" screws, attach shoe to vehicle.
2. Slip the Golight® into the shoe. Verify that the spring lock secures the Golight® into the shoe. An optional magnetic mounting shoe is available (see accessory sheet).

#### OPERATION OF GOLIGHT®

1. Place your Golight® into the mounting shoe or attach to the outside of your vehicle (see mounting instructions).

2. Plug your Golight® into your vehicle's cigarette lighter outlet or 12 Volt direct battery hookup.
3. Using the remote control, turn on the light by depressing the on/off button.
4. With the 4-way arrows on the remote control, rotate your light to the desired location.
5. Unplug and remove light from vehicle. Store the light in optional carrying case when not in use to extend the life of your Golight®.
6. The spotlight should not be turned on when the snap on lens cover (rockguard) is attached.

**WARNING:** Unplug unit when not in use.

#### BULB REPLACEMENT

The Golight® utilizes a Philips® H-9 bulb, which may be purchased

[www.magnalight.com](http://www.magnalight.com)  
1-800-369-6671  
903-498-3363  
[sales@magnalight.com](mailto:sales@magnalight.com)

Driving  
with basic  
risk of

★ This light is for off road and utility use only. It is not designed for road use as a driving light.

For safe and efficient operation of your Golight®, observe these guidelines:

- Using your Golight® in **icing conditions could damage the gear motors.**
- Water can be removed from inside the light by peeling the rubber suction cup from the base and then replacing it securely.
- It is important to keep the suction cup clean and free from damage.