

HML Series

Handheld Spotlight with Magnetic Base Instruction Manual

Thank you for your purchase of the HML Series Handheld Spotlight with Magnetic Base. These instructions will cover how to operate the light as well as bulb replacement.

The light features a magnetic base that allows it to attach to any metal surface – the mount has gripping power up to 100lbs. When removing, do not drag the magnetic base to disconnect, as it may scratch the surface/paint.

OPERATION

- Use the handle on the back of the light to tilt up/down and pan left/right.
- Adjust the tightness of pivot/pan movement using the tightening bolts on the side of the base hinge.
- Connect the SAE connector from power cord to light.
- Plug power plug into power source and flip the switch on back to turn light on.

NOTE: *Check for proper voltage before use! Voltage is 12v DC.*

BULB REPLACEMENT

To replace the bulb remove the rubber ring surrounding the light. Take the face ring off of the lamp and pull the bulb out of the socket freeing it from the screw fasteners. Place the new bulb in its socket and replace face ring.



THESE INSTRUCTIONS MAY NOT COVER ALL DETAILS OR VARIATIONS OF THIS PRODUCT FOR YOUR EQUIPMENT OR INSTALLATION REQUIREMENTS. SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT SALES@LARSONELECTRONICS.COM OR BY PHONE AT 1-800-369-6671 FOR FURTHER ASSISTANCE.

PLEASE VISIT LARSONELECTRONICS.COM FOR **WARRANTY** AND **RETURN** INFORMATION.