

MMP-1 Magnetic Mounting Plate Instruction Guide

Thank you for your purchase of the Larson Electronics MMP-1 Magnetic Mounting Plate. Please follow the steps below in order to operate and maintain this product.


The MMP-1 Magnetic Mounting Plate from Larson Electronics is a 6.5 inch square plate for permanent and magnetic mounting Remote Controlled Spotlights.

This plate contains the mounting pattern for Golight Radioray Spotlights and Golight Stryker Spotlights. This plate can also be mounted to any non-ferrous (fiberglass, etc.) surface so that lights with magnetic bases can be attached to this mounting plate.

INSTALLATION

1. Place steel plate over flat surface.
2. Align holes and use self-tapping screws to secure plate to surface. Use fiberglass safe screws when attaching to a boat.
3. Tighten each screw until snug.
4. Once all screws are installed and tight, attach your magnetic device to the mount.

Note: This plate WILL NOT work for permanent mount Strykers. The GL-5XXX and GL-7XXX series shoes will not bolt onto this plate; magnetic mount shoes will still attach to the plate but will not bolt down.



THESE INSTRUCTIONS MAY NOT COVER ALL DETAILS OR VARIATIONS OF THIS PRODUCT FOR YOUR EQUIPMENT OR INSTALLATION REQUIREMENTS. SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT SALES@LARSONELECTRONICS.COM OR BY PHONE AT 1-800-369-6671 FOR FURTHER ASSISTANCE.

PLEASE VISIT LARSONELECTRONICS.COM FOR **WARRANTY** AND **RETURN** INFORMATION.